


HAWLE PRODUCT RANGE



- | | |
|--|---|
| 1. Elypso Valve Flanged Ends | 25. Socket Clamp, for PVC |
| 2. Elypso Reducing Valve | 26. ISO Fitting Male Adaptor, Acetal |
| 3. Elypso Valve, Socket Ends for PVC | 27. ISO Fitting Elbow 90°, Acetal |
| 4. Elypso Valve, Socket Ends for Cast Iron | 28. Wall Inlet Fitting |
| 5. Combi-T, Single Valve Tee | 29. Double Flanged Bend 90° |
| 6. Combi-III, Triple Valve Tee | 30. All Flanged Tee |
| 7. Combi-T, Socket Ends | 31. Collar Without Thread |
| 8. Concentric Taper | 32. Flanged Duck Foot Bend With PVC Socket 90° |
| 9. Spigot Socket Valve | 33. Double Flanged Duck Foot Bend 90° |
| 10. Corrosion Free Hydrant - Rigid Type | 34. Repair Clamp, Single lug |
| 11. Above Ground Hydrant - Break Away | 35. Universal Pipe Saddle |
| 12. Below – Ground Hydrant | 36. Shut-Off Saddle With O-Ring |
| 13. Air-Release Hydrant | 37. Universal Pipe Saddle, Flanged Outlet |
| 14. Automatic Air Valve | 38. Pipe-Lock-Ring |
| 15. Service Valve | 39. Restraint Flange Adaptor For Cast Iron |
| 16. Service Valve | 40. Double Chamber Flange Adaptor For Cast Iron |
| 17. Service Valve | 41. Restraint Flange Adaptor For PVC |
| 18. Service Valve | 42. ISO Pipe Flange Adaptor For PE |
| 19. Water Meter Console | 43. Double Chamber Flange Adaptor For PVC |
| 20. Restraint Clamp, for PVC | 44. Double Chamber Flange Adaptor For PVC, reducing |
| 21. Endcap | 45. Extension Spindle For Service For Valves |
| 22. Restraint Collar, for PVC | 46. Telescope Extension Spindle For Valves |
| 23. Haku Saddle for Plastic Pipes | 47. Surface Box Adjustable |
| 24. Haku Shut-Off-Saddle | 48. Handwheel |